



#### Reaction Phaser Instruction Manual





May be covered by one or more of the following: U.S. Patents #4538297, 4647876, 4096044, 4745309, 4881047, 4893099, 5124657, 5263091, 5268527, 5319713, 5333201, 5402498 and 5493617.

Other patents pending. Foreign patents pending.

#### Compliance

Standard(s):



Your Reaction Phaser™ pedal has been tested and complies with the following Standards and Directives as set forth by the European Union:

Council Directive(s): 89/336/EEC Electromagnetic Compatibility

This means that this product has been designed to meet stringent guidelines on how much RF energy it can emit, and that it should be immune from other sources of interference when properly used. Improper use of this equipment could result in increased RF emissions, which may or may not interfere with other electronic products.

EN55013, EN50082-1

To insure against this possibility, always use good shielded cables for all audio input and output connections. This will help insure compliance with the Directive(s).

For more information about other Rocktron products, please see your local dealer or one of our importers closest to you (listed on the Rocktron website (www rocktron com)

Read all instructions contained in this manual. Keep these instructions Heed all warnings Follow all instructions. Do not use this apparatus near water. Clean with dry cloth

Copyright © 2009 GHS Corporation All Rights Reserved.

#### Precautions

Refer all service to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power supply or plug is damaged, liquid has been spilled or objects have fallen into the apparatus or if the apparatus has been exposed to rain or moisture, does not operate normally or has been dropped.

DO NOT ATTEMPT TO SERVICE THIS EQUIPMENT. QUALIFIED PERSONNEL SHOULD SERVICE THIS EQUIPMENT ONLY. DO NOT MAKE ANY INTERNAL ADJUSTMENTS OR ADDITIONS TO THIS EQUIPMENT AT ANY TIME OR TAMPER WITH INTERNAL ELECTRONIC COMPONENTS AT ANY TIME. FAILURE TO FOLLOW THESE INSTRUCTIONS MAY VOID THE WARRANTY OF THIS FOLIPMENT AS WELL AS CAUSING A SHOCK HAZARD

#### OPERATING TEMPERATURE

Do not expose this unit to excessive heat. This unit is designed to operate between 32 F and 104 F (0 C and 40 C). This unit may not function properly under extreme temperatures.

Do not block any ventilation openings (if applicable). Install in accordance with the manufacturer's instructions

Do not install near any heat sources such as radiators, heat registers, stoves or other apparatus (including amplifiers) that produce heat.

This product is not equipped with a plug or cable. This pedal runs on a 9 Volt Battery, if a 9Volt DC adapter is the used please follow adapter manufacturer's operation instructions. Only used attachments/accessories specified by the manufacturer.

Do not use this product with any case, stand tripod, bracket or table that is not specified by the manufacturer. Insure that the case, stand, tripod, bracket etc. is properly adjusted and setup (follow all instructions). Extra care and caution should be taken to avoid tip over and injury.

Unplug this apparatus during lightening storms or when unused during long periods of time.

#### Introduction

Set your phasers for stun, gang! Rocktron brings you the Reaction Phaser, a classic phaser pedal that will add a great effect to your arsenal.

Rocktron's Reaction Series pedals are built into a rugged metal slim form factor chassis, taking up as little space as possible on your pedalboard. The Reaction Phaser is a TRUE BYPASS pedal: when you turn it off...it is out of your signal path!

The Reaction Phaser is very easy to use. Just set the SPEED control and off you go. The SPEED knob controls the speed of the modulation waveform. Simple!

A phaser is one of those effects that does not have a stringent placement within the signal chain. Some players love it first in the chain, while others like it after the distortion. Some even love it at the end of the chain.

### Introduction continued.....

Placing the Reaction Phaser first in the chain in front of your distortion or directly into your amp will produce a grainy, gritty effect that adds excitement to your playing. Conversely, if placed after your distortion pedal, or within the effects loop of an amp, it will produce a smoother effect. Experiment and find what works best for you.

You ain't talkin' about phasers unless your talking about the Reaction Phaser! It's that classic phaser sound with true bypass to boot.

The footswitch on the Reaction Phaser controls On/Off status as shown by the LED indicator. Reaction stomp boxes run on a 9V Alkaline battery, or may also be powered by Rocktron's DC OnTap Universal Power Supply adaptor.


# Descriptions



- Descriptions continued......
- SPEED Control This control determines how quick (or the speed) of the phaser waveform.
- 2 9VDC Input This input jack provides 9VDC power to the pedal from the Rocktron DC OnTap 9V power supply (sold seperately).
- 3 ON/OFF Leds These LEDs shows if the pedal is on or off. When the LED is lit the pedal is on. When the LED is not lit the pedal is off.
- BATTERY COMPARTMENT and COVER
   The 9V battery can be found in this compartment.
- 5 INPUT Jack Using a standard 1/4" guitar cable, plug your guitar into this jack.

- Descriptions continued......
- 6 THUMB SCREWS for Battery Compartment. Unscrew these thumb screws to access the battery compartment.
- 7 FOOTSWITCH Use this switch to turn on or off the pedal. The On/Off Led will show you if the pedal is on or off.
- 8 OUTPUT Jack Using a standard 1/4" guitar cable you can plug in another pedal from this jack or plug directly into your amplifier.

## **Typical Connection**



## Specifications

Maximum Input -7dBu Maximum Output -3dBu Imput Impedance  $470k\Omega$ Output Impedance  $10k\Omega$ Current Consumption 20mA Power Requirements 9V Alkaline Battery or Rocktron DC OnTap Univeral Power Supply (sold seperately) Negative tip DC 9V Dimensions

Dimensions

125mm x 78mm x 61mm 5" x 3.25" x 2.5"

Weight

0.7kg 1.5lbs

#### How to change the battery:

To change the battery, remove the thumb screws on the top of the pedal and remove the battery compartment cover. Remove the old battery and replace it with a new 9V Alkaline battery. Replace battery in the same area as the old battery was located. Place the battery compartment cover on the pedal and re-insert the thumb screws.

Save yourself tons of money in batteries by using the Rocktron DC OnTap Universal Power Supply to power this pedal (sold seperately). The Rocktron DC OnTap provides a constant flow of power to the pedal, unlike a battery that will degrade over time. The Rocktron DC OnTap Univeral Power Supply can also power up to 20 pedals and can be used with both 110V and 220V power sources.

Check, www.rocktron.com for more information on the DC OnTap and where to purchase.



Rocktron - A Division of GHS Corporation 2813 Wilber Ave Battle Creek MI 49037 USA

www.rocktron.com info@rocktron.com tel: 1-269-968-3351