

ROCKTRON
TECHNOLOGY FOR GUITARISTS

VELOCITY[®]

V10

ELECTRIC GUITAR AMPLIFIER

User's Manual

Rocktron -A Division of GHS Corporation

2813 Wilber Avenue

Battle Creek MI 49015

USA

Rocktron Phone: 1-(269)-968-3351

Email: info@rocktron.com

Check us out on the web at:

www.rocktron.com

Velocity[®] is a registered trademark of GHS Corporation Battle Creek MI, USA

May be covered by one or more of the following: U.S. Patents #4538297, 4647876, 4696044, 4745309, 4881047, 4893099, 5124657, 5263091, 5268527, 5319713, 5333201, 5402498 and 5493617.

Other patents pending. Foreign patents pending.



Your Rocktron Velocity V10 amplifier has been designed to comply with the following Standards and Directives as set forth by the European Union:

Council Directive(s): 89/336/EEC, 73/23/EEC, 76/769/EC, 1994/62/EC, 2000/53/EC, 2002/95/EC

Standard(s): EN55022, EN50082-1, EN60065

This means that this product has been designed to meet stringent guidelines on how much RF energy it can emit, and that it should be immune from other sources of interference when properly used. Improper use of this equipment could result in increased RF emissions, which may or may not interfere with other electronic products.

To insure against this possibility, always use good shielded cables for all audio input connections. This will help insure compliance with the Directive(s).

V10 Specifications

Power Output	10 Watts
Speakers	1 x 6.5" Custom Voiced Velocity Speaker by Rocktron
EQ	Bass Treble
Headphone Output	One 1/4" jack
Channels	DISTORTION Switch
Dimensions	256mm(W) x 152mm(D) x 304mm(H) 10" x 6" x 12"
Weight	9.9lbs (4.5KG)
Power Requirements	100 Volts AC 50/60Hz or 117 Volts AC, 60Hz or 220/240 Volts AC, 50/60Hz, as specified on chassis
Fuse	100-120V - use F500mA 220-240V - use F300mA



Precautions

NOTE: IT IS VERY IMPORTANT THAT YOU READ THIS SECTION TO PROVIDE YEARS OF TROUBLE FREE USE. THIS UNIT REQUIRES CAREFUL HANDLING.

- All warnings on this equipment and in the operating instructions should be adhered to and all operating instructions should be followed.
- Do not use this equipment near water. Care should be taken so that objects do not fall and liquids are not spilled into the unit through any openings.
- The power cord should be unplugged from the outlet when left unused for a long period of time.
- Do not block any ventilation openings (if applicable). Install in accordance with the manufacturer's instructions.
- Do not install near any heat sources such as radiators, heat registers, stoves or other apparatus (including amplifiers) that produce heat.
- Only used attachments/accessories specified by the manufacturer.
- Do not use this product with any case, stand tripod, bracket or table that is not specified by the manufacturer. Insure that the case, stand, tripod, bracket etc. is properly adjusted and setup (follow all instructions). Extra care and caution should be taken to avoid tip over and injury.
- Unplug this apparatus during lightning storms or when unused during long periods of time.


Refer all service to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power supply or plug is damaged, liquid has been spilled or objects have fallen into the apparatus or if the apparatus has been exposed to rain or moisture, does not operate normally or has been dropped.

DO NOT ATTEMPT TO SERVICE THIS EQUIPMENT. THIS EQUIPMENT SHOULD BE SERVICED BY QUALIFIED PERSONNEL ONLY. DO NOT MAKE ANY INTERNAL ADJUSTMENTS OR ADDITIONS TO THIS EQUIPMENT AT ANY TIME. DO NOT TAMPER WITH INTERNAL ELECTRONIC COMPONENTS AT ANY TIME. FAILURE TO FOLLOW THESE INSTRUCTIONS MAY VOID THE WARRANTY OF THIS EQUIPMENT, AS WELL AS CAUSING SHOCK HAZARD.

OPERATING TEMPERATURE

Do not expose this unit to excessive heat. This unit is designed to operate between 32° F and 104° F (0° C and 40° C). This unit may not function properly under extreme temperatures.

FRONT PANEL DESCRIPTIONS



- ① **INPUT jack**
Connect the output of your guitar to the 1/4" input jack with a shielded guitar cable.

DISTORTION

- ② **GAIN control**
This knob determines the amount of GAIN (or distortion) added to the signal when the distortion is "ON." Turning the knob clockwise will add more GAIN to the signal. Turning the knob counter-clockwise will decrease the amount of GAIN added to the signal.
- ③ **DISTORTION ON/OFF Button**
This button allows you to turn the DISTORTION "ON" or "OFF". When the button is pressed in, the DISTORTION is "ON". When the button is out, the DISTORTION is "OFF."

- ④ **VOLUME control**
This knob determines the overall VOLUME (or level) of the amplifier. Turning the knob clockwise will increase the VOLUME. Turning the knob counter-clockwise will decrease the VOLUME.

EQUALIZATION

- ⑤ **TREBLE control**
This knob controls the overall TREBLE of both the CLEAN and DISTORTION channels. The TREBLE control boosts or cuts the amount of high frequencies present in the signal.
- ⑥ **BASS control**
This knob controls the overall bass of both the DISTORTION and CLEAN channels. The BASS control boosts or cuts the amount of low frequency, or bass sound in the signal.
- ⑦ **HEADPHONE jack**
Plugging your headphones into this jack disconnects the sound going to the speaker and allows you to practice in private.
- ⑧ **POWER switch**
Turns the amp ON and OFF. When the LED is lit, the amp is on.

BACK SIDE (not shown)

POWER CORD

Plug the amplifier into any standard wall outlet. Please be sure to check your local wiring and voltage to make sure your amplifier is the proper voltage for your area of the world. Please follow all the precaution guidelines found in the front of this manual.